

HYTORC

TOOL MODEL: ICE .7 PRESSURE/TORQUE CONVERSION CHART

Standard Torque Chart

PRESSURE IN PSI	TORQUE IN			PRESSURE IN BAR
	FT. LBS.	KGM	NM	
1500	117	16	158	104
1600	125	17	169	110
1800	141	20	191	124
2000	158	22	214	138
2200	174	24	235	152
2400	190	26	257	165
2600	206	28	279	179
2800	222	31	301	193
3000	238	33	322	207
3200	254	35	344	220
3400	270	37	366	234
3600	286	40	388	248
3800	302	42	410	262
4000	318	44	431	276
4200	334	46	453	290
4400	351	48	475	303
4600	367	51	497	317
4800	383	53	519	331
5000	399	55	541	345
5200	415	57	563	358
5400	431	60	585	372
5600	447	62	606	386
5800	463	64	628	400
6000	480	66	650	414
6200	496	69	672	427
6400	512	71	694	441
6600	529	73	716	455
6800	545	75	739	468
7000	561	78	761	482
7200	578	80	783	496
7400	594	82	805	510
7600	610	84	827	524
7800	627	87	850	538
8000	643	89	872	552
8200	659	91	894	565
8400	676	93	916	579
8600	692	96	938	593
8800	708	98	960	607
9000	725	100	982	620
9200	741	102	1004	634
9400	757	105	1026	648
9600	773	107	1048	662
9800	790	109	1070	676
10000	806	111	1092	690